

# EASY ROOTER

## Parts List and Diagram

| CAT. NO.   | DESCRIPTION  | CAT. NO. | DESCRIPTION   |
|------------|--|----------|---|
| ER-100-1   | Frame Complete<br>(Serial #1800 & Over)                                      | ER-207   | Air Foot Switch & Reverse<br>Switch (Ser. #1938 & Over) |
| ER-101-1   | Frame Only<br>(Serial #1800 & Over)  | ER-207-A | Box only w/ Cover & Screws                              |
| ER-101-1-A | Handle Socket  | ER-207-B | Foot Pedal and Hose                                     |
| ER-101-1-B | Handle Hinge Bolt  | ER-207-C | Cable Tie   |
| ER-102     | 10" Rubber Wheel (1)   | ER-207-D | Foot Pedal  |
| ER-103     | Axle   | ER-207-E | Power Switch Diaphragm                                  |
| ER-103-A   | Locknuts (2)   | ER-207-F | Air Hose  |
| ER-103-B   | Spacer Washers (6)   | ER-207-G | Rev. Switch Only (3-Way)                                |
| ER-104     | Wheel Spacer   | ER-207-H | Boot for Reverse Switch                                 |
|            |  | ER-207-J | Barbed Adapter  |
|            |  | ER-207-N | Strain Relief Nut                                       |
| ER-105-1   | Handle with Knobs<br>(Serial #1800 & Over)                                   | ER-208   | V-Belt (52")<br>(Thru Ser. #ER85118)                    |
| ER-105-1-A | Handle Locking Knob (2)<br>(Serial #1800 & Over)                             | ER-208-1 | V-Belt (53")<br>(Ser. #ER85119 & Over)                  |
| ER-108     | Drum Support Shaft   | ER-209   | V-Belt Tension Spring                                   |
| ER-109     | Bronze Thrust Washer   | ER-211   | Belt Guard for GE Motor<br>(Through Serial #4245)       |
| ER-110     | Felt Washer  | ER-211-1 | Belt Guard for A.O. Smith<br>Motor (Ser. #4246 & Up)    |
| ER-111     | Drum Hub Retaining Washer  | ER-211-2 | Belt Guard with Slot for Stud                           |
| ER-112     | Drum Shaft Retaining Bolt<br>for Large & Small Drum                          | ER-212   | Motor Support Bracket<br>with Guide Bolts               |
| ER-201-1   | 1/3 hp Motor Complete with<br>GFI, Air Foot Switch &<br>Reverse Switch Assy. | ER-213   | Nuts, Bolts, Washers (4)                                |
| ER-201-C   | Knob for Belt Guard  | ER-300   | Large Open Cage<br>(For 3/4" & 5/8" Cables)             |
| ER-204-1   | Slip Clutch  | ER-302   | Drum Hub with Bearings                                  |
| ER-204-A   | Fixed Pulley Half  | ER-302-A | Drum Hub Bearings (Set)                                 |
| ER-204-B   | Spacer   | ER-302-B | Retaining Ring (2)                                      |
| ER-204-C   | Moveable Pulley Half   | ER-302-C | Bolts & Lock Washers (12)                               |
| ER-204-D   | Spring   | ER-303   | Cable Locking Thumb Screw                               |
| ER-204-E   | Thrust Washer  | ER-310   | Drum Conn. Cable & Lug                                  |
| ER-204-F   | Thrust Bearing   | ER-350   | Small Open Cage<br>(For 1/2" Cables)                    |
| ER-204-G   | Retaining Ring   | ER-353   | Cable Locking Thumb Screw                               |
| ER-205     | 20' Power Cord w/Plug &<br>Ground Fault Interrupter                          | ER-354   | Small Drum Retaining Bolt<br>(Through Serial #1799)     |
|            |  | GFI-ER   | Ground Fault Interrupter<br>with 20 ft. Cord            |
|            |  | ER-DECAL | Set of Safety Decals                                    |
|            |  | ER-VIDEO | Instructional Video                                     |

**General Wire Spring Co.**

# EASY ROOTER SCHEMATIC DIAGRAM

